

Manual, Assembly instruction: Brodit 836049

Console mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip mount. It is important to install the mount first: any device holder & equipment is to be attached after the mount is in place.

1. Use the enclosed alcohol pad to clean the area where the mount will be installed. Peel off the adhesive tape cover. Place the mount over the center console frame so the right edge hooks over the frame surrounding the compartment.

2. Press downward on the left side of the mount and hook the lower edge around the center console frame.

3. Press upward on the lower part so the edge hooks into place properly.

4. The ProClip mount is in place.