

## Manual, Assembly instruction: Brodit 836052

Console mount



**Please read all of the instructions and look at the pictures before attaching the ProClip mount. It is important to install the mount first: any device holder & equipment is to be attached after the mount is in place.**

1. Hook the left part of the mount over the center console frame.

2. Pull the right part of the mount away from the center console so the lower edge does not touch the padded edge.

2. Hold the right part on a distance from the center console. Hook the angled lower edge into the gap in the center console sidewall.

4. The ProClip mount is in place.