

Manual, Assembly instruction: Brodit 836057

Console mount



Please read all of the instructions and look at the pictures before attaching the ProClip mount. It is important to install the mount first: any device holder & equipment is to be attached after the mount is in place.

1. Hook the angled edge on the lower right part of the mount under the center console sidewall.
2. Pull the upper part of the mount upward. Keep the upper part of the mount on a distance from the center console frame so the angled edge does not touch it.
3. Hook the angled left part of the mount over the center console frame.
4. The ProClip mount is in place.