

Manual, Assembly instruction: Brodit 836081

Console mount



Please read all of the instructions and look at the pictures before attaching the ProClip mount. It is important to install the mount first: any device holder & equipment is to be attached after the mount is in place.

1. Gently place the mount over the center console frame. Pull the right edge out from the frame so it does not touch the frame. Hook the left edge of the mount over the frame.
2. Pull the right part of the mount away from the frame, in the same time press forward on the right side. Hook the right end of the mount over the frame.
3. Press on the mount so it hooks properly in place.
4. The ProClip mount is in place.