

Manual, Assembly instruction: Brodit 836130

Console mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip mount. It is important to install the mount first: any device holder + equipment is to be attached after the mount is in place. This mount consists of two parts: An mount and a faceplate.

1. Use the enclosed alcohol pad to clean the area where the mount will be installed. Peel off the adhesive tape cover on the mount. Hook the upper edge of the mount over the console frame. Press down on the top of the mount and in on the bottom of the mount. Hook + Clip the lower edge into the gap under the console sidewall. Press up on the bottom of the mount to ensure the lower edge is fully inserted and the tape makes full contact with the console.

2. Place the locking washer into the recess on top of the riser block. Place the faceplate over the riser and angle it as desired. Secure the faceplate to the mount using the included machine screw.

3. The mount may also be placed on the drivers side of the console.

4. The ProClip mount is in place.