

Montageanleitung: Brodit 836132

Console mount

1.)



2.)



3.)



4.)



Bitte vor der Montage die Anleitung aufmerksam lesen und die Bilder ansehen. Es ist wichtig, zuerst die ProClip Halterung zu installieren: Geräte Halterung + Ausrüstung muss angebracht werden, nachdem die Halterung im Platz sitzt. Diese Halterung besteht aus zwei Teile: Eine Kopfplatte und eine Halterung.

1. Die Oberfläche wo die Halterung zu montiert werden ist, mit dem beiliegenden Alkohol-Pad reinigen. Die Schutzfolie vom Klebestreifen an die Halterung entfernen. Die obere Kante der Halterung in den Spalt zwischen dem Seitenwandt des Faches und der blende der Konsole festhaken.

2. Die dünne Ende der beiliegenden "Gap Opener (Spaltöffner)" zum Aufweiten in den Spalt in der Seitenwandt der Konsole drücken, auf beiden Seiten der Halterung. Die Halterung nach unten drücken, so dass sich die Kante in den Spalt zwischen den "Gap Opener (Spaltöffner)n" festhakt. Die "Gap Opener (Spaltöffner)" herausziehen.

3. Place the included locking washer into the recess on top of the mount. Place the faceplate onto the mount. Adjust the faceplate into the desired angle. The faceplate may be installed for use by the driver or passenger. Attach the faceplate to the mount with the included screw.

4. The ProClip mount is in place.