

Manual, Assembly instruction: Brodit 836132

Console mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip mount. It is important to install the mount first: any device holder + equipment is to be attached after the mount is in place. His mount consists of two parts: a faceplate and a mount.

1. Use the enclosed alcohol pad to clean the area where the mount will be installed. Peel off the adhesive tape cover. Hook the upper edge of the mount into the gap between the compartment wall and the console trim.

2. Insert the included Gap Opener (Spaltöffner)s into the gap under the console side panel, one on each side of the mount. Press down on the top of the mount until the lower edge hooks + clips into the gap between the Gap Opener (Spaltöffner)s. Pull out the Gap Opener (Spaltöffner)s.

3. Place the included locking washer into the recess on top of the mount. Place the faceplate onto the mount. Adjust the faceplate into the desired angle. Attach the faceplate to the mount with the included screw. The faceplate may be installed for use by the driver or passenger.

4. The ProClip mount is in place.