

Manual, Assembly instruction: Brodit 836200

Console mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip mount. It is important to install the mount first: any device holder + equipment is to be attached after the mount is in place.

1. Position the mount forward along the right side of the console. Press the upper edge into the gap between the console side and the accent trim.

2. Insert the included Gap Opener (Spaltöffner) into the gap under the console sidewall, to widen the gap.

3. Press down on the top of the mount and pull the lower edge out from the console. Hook + Clip the lower edge of the mount into the gap next to the Gap Opener (Spaltöffner). Pull out the Gap Opener (Spaltöffner). Press on the upper and lower lips to ensure they are fully seated

4. The ProClip mount is in place.