

Manual, Assembly instruction: Brodit 836205

Console mount

1.)

2.)



3.)

4.)



Please read all of the instructions and look at the pictures before attaching the ProClip mount. It is important to install the mount first: any device holder + equipment is to be attached after the mount is in place. This mount consists of two parts: a faceplate and a mount.

1. Align the mount between the park lever and drive mode switch, as shown in the picture. Hook the upper edge of the mount over the console frame edge.

2. Press the thin ends of the enclosed Gap Opener (Spaltöffner) into the gap in the center console sidewall, to widen the gap on each side of the mount. Press downward on top of the mount and press the lower edge toward the console sidewall so the the lower edge snaps + clips into the gap between the Gap Opener (Spaltöffner)s. Adjust the position so the mount sits evenly and properly in the gap. Pull out the Gap Opener (Spaltöffner)s.

3. Place the included locking washer into the recess on top of the mount. Place the faceplate onto the mount. Adjust the faceplate into the desired angle. The faceplate may be installed for use by the driver or passenger. Attach the faceplate to the mount with the included screw.

4. The ProClip mount is in place.