

Manual, Assembly instruction: Brodit 836288

Console mount

1.) 2.)



3.) 4.)



Please read all instructions and review the pictures before installing the ProClip mount. Important: The mount must be installed before attaching any device holder, cradle, or other accessory. This mount consists of two parts: a faceplate and a mount.

1. Gently press the included Gap Opener (Spaltöffner)s into the gap in the console side wall as shown in the picture. Clean the installation area using the enclosed alcohol wipe. Remove the protective liner from the double-sided adhesive tape. Hook the lower edge of the mount into the gap between the Gap Opener (Spaltöffner)s. Gently pulling out on the Gap Opener (Spaltöffner)s will assist the installation. Position the mount so it rests just in front of the bend in the console wall. Lift the upper edge of the mount over the console wall. Press the upper edge into the gap between the console wall and body. Pull out the Gap Opener (Spaltöffner)s.

2. Place the included locking washer into the recess on top of the mount. Place the faceplate onto the mount. Adjust the faceplate into the desired angle. The faceplate may be installed for use by the driver or passenger. Attach the faceplate to the mount with the included screw.

3. The mount may be installed on the drivers or passengers side of the console

4. The ProClip mount is in place.