

Manual, Assembly instruction: Brodit 836301

Console mount

1.)

2.)



3.)

4.)



Please read all of the instructions and look at the pictures before attaching the ProClip mount. It is important to install the mount first: any device holder + equipment is to be attached after the mount is in place. This mount consists of three parts: a faceplate, an attaching piece and a mount.

1. Use the enclosed alcohol pad to clean the area where the mount will be installed. Peel off the adhesive tape cover. Press the thin end of the attaching piece into the gap between the inner side wall and the top frame of the floor console. Press + Flip the piece upward so the edge hooks behind the sidewall.

2. Place the mount onto the floor console frame top. Pull the upper part of the mount upward and hook it over the console edge so the holes are aligned with the holes in the attaching piece. Attach the parts together with the enclosed screws.

3. Place the included locking washer into the recess on top of the mount. Place the faceplate onto the mount. Adjust the faceplate into the desired angle. The faceplate may be installed for use by the driver or the passenger. Attach the faceplate to the mount with the included screw.

4. The ProClip mount is in place.