

Manual, Assembly instruction: Brodit 851893

Center mount

1.)



2.)



3.)



4.)



1. Press the grooved edge on the upper part of the ProClip into the gap between the air vent frame and the padded dashboard at pos. 1. Press until you see or hear/feel it snaps into place.

2. Press the grooved edge on the lower part of the ProClip into the gap between the air vent frame and the padded dashboard ledge at pos. 2. Press until you see or hear/feel it snaps into place.