

Manual, Assembly instruction: Brodit 851936

Angled mount

1.)



2.)



3.)



4.)



Please read all of the instructions before attaching the ProClip.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Peel off the cover of adhesive tape on the ProClip.

2. Press the angled edge on the left side of the ProClip carefully into the gap between the two padded dashboard parts/dashboard side wall at pos. 1. Press the ProClip all the way in and press in the right side of it so the adhesive tape sticks to the dashboard.