

Manual, Assembly instruction: Brodit 851946

Center mount

1.)



2.)



3.)



4.)



Attention! Read all instructions before attaching the ProClip.

1. Open the compartment on the dashboard and press the enclosed gap opener into the gap between the air vent panel frame and the compartment frame at pos.1. to widen the gap.

2. Press the angled edge of the ProClip into the gap next to the gap opener at pos.1. Pull out the gap opener.

3. Pull the lower part of the ProClip downwards and press the grooved edge into the gap between the wood grain climate control panel and the air vent frame at pos.2. Press firmly until you see or hear/feel it snaps into place.