

Manual, Assembly instruction: Brodit 851951

Angled mount

1.)



Attention! Read all instructions before attaching the ProClip

1. Peel off the cover of the adhesive tape on the ProClip. Open the glove compartment. Press the left part of the ProClip, with adhesive tape, into the gap at pos.

1.

2. Press the long right part of the ProClip into the gap at pos.

2. Close the glove compartment.