

## Manual, Assembly instruction: Brodit 851955

Angled mount

1.)



**Attention! Read all instructions before attaching the ProClip.**

**1.** Place the ProClip over the coin holder + ledge at pos.1.

**2.** Press the long upper part of the ProClip into the gap at pos. 1 so the lower part of the ProClip, with angle, snaps into the gap at pos. 2 underneath the ledge.