

Manual, Assembly instruction: Brodit 851959

Center mount

1.)



2.)



3.)



4.)



Attention! Read all instructions before attaching the ProClip.

1. Press the grooved edge on the lower part of the ProClip into the gap between the dashboard and the air vent at pos. 1. Press until you see or hear/feel it snaps into place.

2. Press the grooved edge on the upper part of the ProClip into the gap between the dashboard and the climate control panel at pos. 2. Press until you see or hear/feel it snaps into place.