

Manual, Assembly instruction: Brodit 851989

Angled mount

1.)



Attention! Read all instructions before attaching the ProClip

1. Clean the surface at pos. 2 with the enclosed alcohol pad. Peel off the cover of the adhesive tape on the ProClip.
2. Press the short left part of the ProClip into the gap at pos.
- 1.
3. Press the right part of the ProClip, with adhesive tape, into the gap at pos. 2.