

Manual, Assembly instruction: Brodit 851990

Center mount

1.)



2.)



3.)



4.)



Attention! Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Press the grooved edge on the lower part of the ProClip into the gap between the air vent frame and the stereo. Press until you see or hear/feel it snaps into place.

2. Slide the ProClip to the left. Note: If the gap is tight, press the thin end of the enclosed gap opener into the gap to widen it.

3. Press forward on the upper part of the ProClip so the grooved edge snaps into the gap between the air vent frame and the padded dashboard. Press until you see or hear/feel it snaps into place.

4. The ProClip is in place.