

Manual, Assembly instruction: Brodit 852008

Angled mount



Attention! Read all instructions before attaching the ProClip.

1. Press the grooved edge on the lower part of the ProClip into the gap between the padded part of the dashboard and the air vent frame. Press until you see or hear/feel it snaps into place.

2. Press the grooved edge on the upper part of the ProClip into the gap between the air vent frame and the padded dashboard. Press until you see or hear/feel it snaps into place.

3. The ProClip is in place.

4. The ProClip is in place.