

Manual, Assembly instruction: Brodit 852015

Center mount



1. Press the thin end of the enclosed gap opener into the gap between the center console panel and the dashboard to widen the gap.

2. Press the angled edge on the lower part of the ProClip into the gap next to the gap opener. Pull out the gap opener.

3. Press the ProClip upwards and forward so the grooved edge snaps into the gap between the air vent frame and the padded dashboard. Press until you see or hear/feel it snaps into place.

4. The ProClip in place.