

Manual, Assembly instruction: Brodit 852025

Center mount

1.)



2.)



3.)



4.)



Note: The ProClip can be placed anywhere within the width of the airvent.

1. Press the lower part of the ProClip, with grooved edge, up under the air vent frame.

2. Push the upper part of the ProClip forward and press the grooved edge into the gap between the air vent frame and the padded dashboard. Press until you see or hear/feel it snaps into place.

3. The ProClip in place.