

Manual, Assembly instruction: Brodit 852039

Center mount

1.)



2.)



3.)



4.)



Attention! Read all instructions before attaching the ProClip.

1. Open the compartment on the dashboard and press the enclosed gap opener into the gap between the air vent frame and the compartment frame at pos.1. to widen the gap. Clean the surface at pos. 2 with the enclosed alcohol pad. Peel off the cover of the adhesive tape on the ProClip
2. Hold the ProClip in a horizontal position and press the angled edge on the upper part of the ProClip into the gap next to the gap opener at pos.1. Pull out the gap opener.
3. Flip/pull the lower part of the ProClip down and hook the angled edge, with adhesive tape, under the padded part of the dashboard, below the air vent, at pos.2.