

Manual, Assembly instruction: Brodit 852043

Center mount

1.)



2.)



3.)



4.)



1. Press the grooved edge on the lower part of the ProClip into the gap between the stereo and the air vent frame. Press until you see or hear/feel it snaps into place.

2. Press the grooved edge on the upper part of the ProClip into the gap between the air vent frame and the padded dashboard. Press until you see or hear/feel it snaps into place.

3. The ProClip in place.