

Manual, Assembly instruction: Brodit 852068

Angled mount

1.)



2.)



Attention! Read all instructions before attaching the ProClip.

1. Press the curved edge on the lower part of the ProClip under the edge at 1.
2. Press the grooved edge on the upper part of the ProClip into the gap at 2.