

Manual, Assembly instruction: Brodit 852082

Angled mount

1.)



Attention! Read all instructions before attaching the ProClip.

1. Open the glove compartment. Remove the screw at pos.

1. Clean the surface at pos. 1 and pos. 2 with the enclosed alcohol pad. Peel off both adhesive tape covers on the ProClip.

2. Press + hook the angled edge on the right side of the ProClip under the edge of the glove compartment frame at pos.

1. Screw in the screw.

3. Hook the left side of the ProClip, with angled edge, over the padded edge and press the angled edge into the gap between the padding and climate control panel frame at pos. 2.