

Manual, Assembly instruction: Brodit 852083

Center mount

1.)



2.)



3.)



4.)



1. Hold the ProClip so the face is in a horizontal position and press the curved edge on the upper part of the ProClip into the gap between the padded dashboard and the air vent frame.

2. Flip the ProClip downwards so the curved edge hooks under the air vent frame in the padded dashboard

3. Press the grooved edge on the lower part of the ProClip into the gap between the air vent frame and the padded part of the dashboard. Press until you see or hear/feel it snaps into place.

4. The ProClip in place.