

Manual, Assembly instruction: Brodit 852101

Center mount

1.)



Attention! Read all instructions before attaching the ProClip

1. Clean the surface at pos. 2 with the enclosed alcohol pad. Peel off the adhesive tape cover on the ProClip.

2. Press the upper part of the ProClip, with groove, into the gap at pos.

1.

3. Press the lower part of the ProClip, with adhesive tape, against the dashboard at pos.

2. Press until the adhesive tape attaches.