

Manual, Assembly instruction: Brodit 852106

Center mount

1.)



2.)



3.)



4.)



Attention! Read all instructions before attaching the ProClip.

1. Press the thin end of the enclosed gap opener into the gap between the air vent frame and the control panel frame to widen the gap.

2. Press the grooved edge on the lower part of the ProClip into the gap next to the gap opener. Press until you see or hear/feel it snaps into place. Pull out the gap opener.

3. Press the thin end of the enclosed gap opener into the gap between the air vent frame and the padded dashboard, next to the ProClip, to widen the gap. Press forward on the upper part of the ProClip so the grooved edge goes into the gap. Press until you see or hear/feel it snaps into place. Pull out the gap opener.

4. The ProClip is in place.