

Manual, Assembly instruction: Brodit 852111

Center mount

1.)



2.)



3.)



4.)



Attention! Read all instructions before attaching the ProClip.

1. Clean the surface at pos. 2 with the enclosed alcohol pad. Peel off both adhesive tape covers on the ProClip.

2. Press the grooved part of the ProClip into the gap between the air vent frame and the padded dashboard at pos. 1. Press until you see or hear/feel it snaps into place.

3. Press the lower part of the ProClip, with adhesive tape, against the padded ledge at pos. 2. for best possible attachment.