

Manual, Assembly instruction: Brodit 852115

Center mount

1.)



2.)



3.)



4.)



Peel off the cover of the adhesive tape on the ProClip.

1. Press the grooved edge on the left side of the ProClip into the gap between the padded dashboard edge and the panel frame surrounding the stereo/climate control. Press until you see or hear/feel it snaps into place.

2. Press the grooved edge on the right side of the ProClip into the gap between the console wall and the dashboard. Press until you see or hear/feel it snaps into place.

3. The ProClip is in place.

4. The ProClip is in place.