

Manual, Assembly instruction: Brodit 852127

Center mount, big

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Clean the surface at pos. 2. with the enclosed alcohol pad. Press the thin end of the enclosed gap opener into the gap between the frame surrounding the air vent and the dashboard, to widen the gap. Peel off cover of adhesive tape on the ProClip.

2. Press the grooved edge on the upper part of the ProClip into the gap next to the gap opener at pos. 1. Pull out the gap opener.

3. Press forward on the lower part of the ProClip for best possible attachment of the adhesive tape at pos. 2.

4. The ProClip is in place.