

Manual, Assembly instruction: Brodit 852129

Center mount



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Press the thin end of the enclosed gap opener into the gap between the panel surrounding the display and the frame surrounding the air vent, to widen the gap.
2. Press the curved edge on the upper part of the ProClip into the gap next to the gap opener. Flip the ProClip downward so the curved edge hooks under the panel surrounding the display.
3. Press the lower part of the ProClip upward/forward so the grooved edge goes into the gap between the air vent and the surrounding frame. Press until you hear/feel it snaps into place. Pull out the gap opener.
4. The ProClip is in place.