

Manual, Assembly instruction: Brodit 852151

Center mount

1.)



2.)



3.)



4.)



Attention: Please read all of the instructions and look at the pictures before attaching the ProClip. Note: The ProClip can be positioned within the width of the stereo.

1. Clean the surface between the stereo and the air vent panel frame with the enclosed alcohol pad. Peel off the cover of adhesive tape on the ProClip. Press the lower part of the ProClip, with adhesive tape, into the gap between the stereo and the air vent panel frame. Press it all the way in.

2. Press the thin end of the enclosed gap opener into the gap between the air vent panel frame and the padded dashboard next to the ProClip to widen the gap.

3. Push the upper part of the ProClip over the panel frame so the angled edge snaps into the gap next to the gap opener. Pull out the gap opener.

4. The ProClip is in place