

Manual, Assembly instruction: Brodit 852169

Center mount

1.)



2.)



3.)



4.)



1. Press the grooved edge on the lower part of the ProClip into the gap between the padded part of the dashboard and the air vent frame. Press until you see or hear/feel it snaps into place.

2. Push the upper part of the ProClip forward and place the grooved edge on top of the air vent frame.

3. Press the grooved edge on the upper part of the ProClip into the gap between the air vent frame and the padded part of the dashboard. Press until you see or hear/feel it snaps into place.

4. The ProClip in place.