

Manual, Assembly instruction: Brodit 852187

Angled mount

1.)



2.)



3.)



4.)



1. Press the thin end of the enclosed gap opener into the gap between the compartment frame and the padded part surrounding the vertical air vent frame to widen the gap.

2. Press the grooved edge on the right side of the ProClip into the gap next to the gap opener.

3. Hook the angled edge on the left side of the ProClip into the gap between the horizontal air vent panel and the surrounding panel frame. Pull out the gap opener.

4. The ProClip in place.