

Manual, Assembly instruction: Brodit 852198

Center mount

1.)



2.)



3.)



4.)



1. Press the curved edge on the lower part of the ProClip up into the gap between the air vent frame and the wood grain panel.

2. Press forward on top of the ProClip so the grooved edge goes into the gap between the dashboard ledge and the wood grain panel. Press until you see or hear/feel it snaps into place.

3. The ProClip is in place.

4. The ProClip is in place.