

Manual, Assembly instruction: Brodit 852244

Center mount

1.)



2.)



3.)



4.)



1. Press the grooved edge on the upper part of the ProClip into the gap between the air vent panel frame and the padded dashboard. Press until you see or hear/feel it snaps into place.

2. Press the grooved edge on the lower part of the ProClip onto the gap between the air vent panel frame and the padded part of the dashboard by pressing down and in at the same time.

3. If you didn't get the ProClip all the way in, press forward on the lower part of the ProClip until you see or hear/feel it snaps into place.

4. The ProClip is in place.