

Manual, Assembly instruction: Brodit 852248

Center mount

1.)



2.)



3.)



4.)



Peel off the cover of the adhesive tape on the ProClip.

1. Loosen the screw in the instrument panel frame by using a screwdriver. Press the thin end of the enclosed gap opener into the gap between the panel frame and the padded dashboard overhang to widen the gap.

2. Press the curved edge on the lower part of the ProClip into the gap between the dashboard panel and the surrounding wood grain panel frame. Flip the ProClip forward towards the dashboard overhang.

3. Press upwards and forward on the upper part of the ProClip so the angled edge snaps into the gap between the panel frame and the padded dashboard overhang next to the gap opener. Pull out the gap opener and tighten the screw.

4. The ProClip in place.