

Manual, Assembly instruction: Brodit 852280

Center mount

1.)



2.)



3.)



4.)



Attention! Read all instructions before attaching the ProClip.

1. Press the enclosed gap opener into the gap between the air vent frame and the padded dashboard at pos.1. to widen gap.
2. Press the grooved edge on the lower part of the ProClip into the gap next to the gap opener at pos.1. Press firmly until you see or hear/feel it snaps into place. Pull out the gap opener.
3. Press the enclosed gap opener into the gap between the air vent frame and the padded dashboard at pos.2. to widen gap.
4. Press the grooved edge on the upper part of the ProClip into the gap next to the gap opener at pos.2. Press firmly until you see or hear/feel it snaps into place. Pull out the gap opener.