

Manual, Assembly instruction: Brodit 852283

Center mount



Attention! Read all instructions before attaching the ProClip.

1. Press the grooved edge on the lower part of the ProClip into the gap at pos. 1.
2. Hook the angled edge on the upper part of the ProClip into the gap between the air vent frame and the dashboard at pos. 2. Note: If any of the gaps is too tight, press the thin end of the enclosed gap opener into the gap to widen the gap.
3. The ProClip is in place.
4. The ProClip is in place.