

Manual, Assembly instruction: Brodit 852285

Center mount

1.)



2.)



3.)



4.)



Attention! Read all instructions before attaching the ProClip

1. Press the lower part of the ProClip, with groove, into the gap at pos. 1.
2. Hook the upper part of the ProClip, with angle, into the gap above the air vent at pos. 2.