

Manual, Assembly instruction: Brodit 852296

Center mount

1.)



2.)



3.)



4.)



Please read all instructions and look at the pictures before attaching the ProClip

1. Press the thin end of the enclosed Gap Opener (Spaltöffner) into the gap below the air vent frame to widen the gap. Press the lower part of the ProClip, with groove, into the gap next to the Gap Opener (Spaltöffner). Pull out the Gap Opener (Spaltöffner).
2. Press the Gap Opener (Spaltöffner) into the gap between the air vent frame and the padded dashboard. Press the upper part of the ProClip into the gap next to the Gap Opener (Spaltöffner). Pull out the Gap Opener (Spaltöffner).
3. Press until you see or hear + feel it snap into place.
4. The ProClip is in place.