

Manual, Assembly instruction: Brodit 852303

Angled mount



This ProClip fits both the Convertible and Coupe & Wagon, with and without wood grain panel in the center dash. Peel off the cover of adhesive tape on the ProClip.

1. Place the ProClip over the center dash console frame.

2. Press forward on the right side of the ProClip so the angled edge hooks over the center dash console frame by the console wall.

3. The ProClip in place.