

Manual, Assembly instruction: Brodit 852306

Center mount



Attention! Read all instructions before attaching the ProClip.

1. Press the grooved edge on the lower part of the ProClip into the gap between the air vent panel frame and the center dash panel frame. Press until you see or hear/feel it snaps into place. If the gap is very tight press the thin end of the enclosed gap opener into the gap next to the ProClip to widen the gap

2. Press forward on the upper part of the ProClip so the angled edge snaps/hooks into the gap between the panel frame and the padded dashboard. Press until you see or hear/feel it snaps into place. If the gap is very tight press the thin end of the enclosed gap opener into the gap next to the ProClip to widen the gap.

3. The ProClip is in place.

4. The ProClip is in place.