

Manual, Assembly instruction: Brodit 852311

Center mount

1.)



Attention! Read all instructions before attaching the ProClip

1. Clean the surface at pos. 2 with the enclosed alcohol pad. Peel off the cover of the adhesive tape on the ProClip.

2. Press the upper part of the ProClip, with groove, into the gap above the air vent at pos.

1.

3. Slide the ProClip towards the steering wheel until it is in position as shown in the picture. Press the lower part of the ProClip, with adhesive tape, into the gap at pos. 2.