

Manual, Assembly instruction: Brodit 852333

Center mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Peel off the adhesive tape covers on the ProClip. Press the angled edge on the lower part of the ProClip into the gap between the frame surrounding the air vent and the control panel
2. Flip the ProClip upward/forward so the angled lower edge hooks behind the control panel.
3. Press the angled edge on the upper part of the ProClip into the gap between the frame surrounding the air vent and the dashboard.
4. The ProClip is in place.