

Manual, Assembly instruction: Brodit 852335

Center mount

1.)



2.)



3.)



4.)



Attention! Read all instructions before attaching the ProClip

1. Press the upper part of the ProClip into the gap above the air vent at pos. 1.
2. Press the lower part of the ProClip into the gap below the air vent at pos. 2.