

Manual, Assembly instruction: Brodit 852348

Center mount



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Peel off the cover of the adhesive tape on the ProClip. Press the grooved edge on the lower part of the ProClip into the gap between the dashboard and the panel surrounding the air vent. Press until you hear/feel it snaps into place.

2. Hook the upper part of the ProClip into the gap between the panel surrounding the air vent and the dashboard. Press down on top of the ProClip so the angled edge hooks properly in place and the adhesive tape attaches.

3. The ProClip is in place.

4. The ProClip is in place.