

Manual, Assembly instruction: Brodit 852350

Angled mount, Low

1.)



2.)



3.)



4.)



Peel off the covers of the adhesive tape on the ProClip

1. Place the ProClip over the center dash console frame, next to the climate control, and press/place the angled edge into the gap between the panel frame and the center dash console wall.

2. Press the ProClip to the left so the angled edge on the left side of the ProClip snaps over the console edge.

3. The ProClip in place.